

200W SINGLE SPEAKER

OLYMPIC

Party Hire

1

WHAT'S INCLUDED:

SPEAKER

1 x 10" BEHRINGER 200W

SPEAKER STAND


1 X PROSTAND (TRI-POD STYLE)

AUDIO JACK > 3.5MM AUX


CONNECTS SPEAKER TO YOUR DEVICE

POWER CABLE

1 X IEC LEAD TO POWER SPEAKERS



SET-UP INSTRUCTIONS:



1

- Plug power cable into speaker/mains and leave switched off

2

- Connect black audio jack to **1/4 INCH INPUT** on the back of the speaker.

3

- Connect 3.5mm AUX to audio device (phone, laptop etc.)

4

- Turn on speaker, begin playing music, adjust volume with **LEVEL** control and adjust **EQ HIGH & LOW** to preferred level.

NEED HELP?
CALL OUR OFFICE

8388 5545



FLIP!

FIND OUT MORE AT WWW.OLYMPICPARTYHIRE.COM.AU

200W SINGLE SPEAKER

OLYMPIC

Party Hire

2



NEED HELP?
CALL OUR OFFICE
8388 5545



FIND OUT MORE AT WWW.OLYMPICPARTYHIRE.COM.AU