

550W / 1000W AUDIO PACKAGE

OLYMPIC

Party Hire

1

WHAT'S INCLUDED:

SPEAKERS ●

2 x 12" or 15" BEHRINGER 550w/1000w

SPEAKER STANDS ●

2 X PROSTANDS (TRI-POD STYLE)

RED/BLACK JACK > 3.5MM AUX ●



CONNECTS SPEAKER TO YOUR DEVICE

XLR CABLE MALE > FEMALE ●

CONNECTS TWO SPEAKERS TOGETHER


POWER CABLES ●

2 X IEC LEAD TO POWER SPEAKERS



SET-UP INSTRUCTIONS:

- 1 Plug power cables into speakers/mains and leave switched off
- 2 Connect red & black audio jacks into **INPUT 1 & INPUT 2** on the back of either speaker system
- 3 Connect 3.5mm AUX to audio device (phone, laptop etc.)

- 
- 4 Connect XLR cable from **LINK OUTPUT** (female) on speaker to the **INPUT 1** (male) on the second speaker.
 - 5 Switch on speakers, begin playing music, adjust volume with **INPUT 1 & 2** control and adjust **EQ HIGH & LOW** to preferred level (on each speaker).

NEED HELP?
CALL OUR OFFICE

8388 5545



FEMALE



MALE

FLIP!

FIND OUT MORE AT WWW.OLYMPICPARTYHIRE.COM.AU

550W/1000W AUDIO PACKAGE

OLYMPIC

Party Hire

2

3



2



1



4



5



NEED HELP?
CALL OUR OFFICE
8388 5545



FIND OUT MORE AT WWW.OLYMPICPARTYHIRE.COM.AU