

550W/1000W SINGLE SPEAKER

OLYMPIC

Party Hire

1

WHAT'S INCLUDED:

SPEAKERS ●

1 x 12" or 15" BEHRINGER 550w/1000w

SPEAKER STANDS ●



1 X PROSTAND (TRI-POD STYLE)

RED/BLACK JACK > 3.5MM AUX ●


CONNECTS SPEAKER TO YOUR DEVICE

POWER CABLES ●

1 X IEC LEAD TO POWER SPEAKER



SET-UP INSTRUCTIONS:



- 1 • Plug power cable into speaker/mains and leave switched off
- 2 • Connect red & black audio jacks into **INPUT 1 & INPUT 2** on the back of the speaker

- 3 • Connect 3.5mm AUX to audio device (phone, laptop etc.)
- 4 • Switch on speaker, begin playing music, adjust volume with **INPUT 1 & 2** control and adjust **EQ HIGH & LOW** to preferred level.

NEED HELP?
CALL OUR OFFICE

8388 5545



FLIP!

FIND OUT MORE AT WWW.OLYMPICPARTYHIRE.COM.AU

550W/1000W SINGLE SPEAKER

OLYMPIC

Party Hire

2



NEED HELP?
CALL OUR OFFICE
8388 5545



FIND OUT MORE AT WWW.OLYMPICPARTYHIRE.COM.AU