

Commercial 4 Burner Stove

Top Cookrite - LPG

Party Hire

WHAT'S INCLUDED:

Cookrite 4 Burner Stove
8.5kg Gas bottle
Gas Regulator Stand



Stove



Gas Bottle



Regulator Stand

SET-UP INSTRUCTIONS:

Connecting Gas Bottle & Regulator

- Place a 9kg gas cylinder on Regulator Stand
- Connect the regulator to the bottle
- Tighten gas bottle connection anti-clockwise. Ensure this is tight enough so the gas engages when the appliance is turned on
- CONNECT gas line from Stove to the regulator noting the grooves that the bayonet lines up with (example to right). Once inserted twist to lock the connection (Important).
- Leak Test: With the gas line connected, turn gas on at bottle and check for leaks. Use soapy water and brush or spray over joints on gas bottle and connection at hotbox and watch for bubbles.



Lighting the pilot light

**** note a lighter is required ****

- Align the control valve knob on the "O" position, so that the valve is closed.
- press the front air valve knob, left 30 degrees, to the fire position (spark symbol)
- At the fire position, completely press the knob, meanwhile light the fire by pilot with another hand. Keep pressing the knob about 10-15 seconds and observe stability of fire.
- If the fire is not lit, please repeat the above steps until the fire is ignited.
- Tip : The pilot light may not be lighted immediately, for existing gas in the pipe. Wait a minute, the pilot light will be lighted after the gas is extinguished



Gas Stove with Gas Hose, which links to the Gas Regulator. The Gas regulator Attaches to the Gas Bottle
Once connected, ensure the gas bottle is a few metres away from the Stove itself

Igniting the main burner

- Revolve the main fire control valve knob anticlockwise after lighting the pilot light, and then the main fire burner is ignited by the pilot light.
- When knob is turned to 90 degrees, burner is in the maximum power (Fig.4). Press and turn the knob to revolve it anticlockwise, the power of burner reduces gradually with the rotation angle increases



Figure 2




Figure 3




Figure 4




Figure 5

NEED HELP?
CALL OUR OFFICE

8346 5545



OUT OF HOURS SUPPORT: 1300 161 024