

## WHAT'S INCLUDED:

- Large Electric Hot Box (Apuro)
- Includes
- 8 racks
- IEC Power Cord



Apuro Heated Banquet Cabinet – Quick User Guide  
 For: First-time hire use of the Apuro Heated Banquet Cabinet CP829-A  
**Before You Start**

- Place the cabinet on a flat, stable surface.
- Lock the castor brakes before use.
- Plug into a standard 240V power outlet via the IEC power cable
- Ensure ventilation space around the unit.

### Operating Instructions

1. Power On
  - Switch the unit ON using the power switch.
  - Set the temperature between 70°C and 82°C using the thermostat.
2. Pre-Heat
  - Allow approximately 10–15 minutes for the cabinet to fully heat before loading food.
  - Keep doors closed during pre-heating.
3. Load Food
  - Use compatible gastronorm trays or plated meals.
  - Open doors carefully – hot air will escape.
  - Spread trays evenly for best airflow and heating.
  - Do not overload shelves.
4. During Use
  - Keep doors closed as much as possible to maintain temperature.
  - Use caution: interior surfaces and trays become very hot.
  - The internal fans circulate heat automatically.
5. After Use
  - Switch OFF and unplug the cabinet.
  - Allow unit to cool completely before cleaning.
  - Wipe interior and exterior with a damp cloth and mild detergent.
  - Do not hose down or immerse in water.

#### Safety Tips

- HOT SURFACE – avoid touching interior walls or trays.
- Do not move the cabinet while loaded with hot food.
- Ensure castor brakes are engaged during service.
- Keep power cord clear of walkways.

#### Troubleshooting

Issue	Solution
Cabinet not heating	Check power outlet and switch is ON
Food not staying hot	Ensure doors remain closed and unit is pre-heated
Unit moves during use	Engage wheel brakes
Uneven heating	Avoid overloading trays and allow airflow

#### Important

This cabinet is designed to hold and transport hot food, not cook food from raw.

For Further detailed user Manual- <https://media.nisbets.com/asset/au/media/user%20manual%20cp829a.pdf>

#### Control panel

The control panel is located above the door on the front of the appliance.	75	Cabinet Temperature Display
		Fan On
		Down button
		On / Off button: Press and hold for 3 seconds to switch system on / off
		Up Button

#### Adjusting the Temperature

1. Press (power symbol) for 1 second. The set temperature will flash.
2. Press the up button or down button to change the set temperature.
3. Wait 6 seconds for the set temperature to be confirmed

**NEED HELP?  
 CALL OUR OFFICE**  
 8346 5545

