

# HEATLIE ROASTER - LPG

OLYMPIC

Party Hire

## WHAT'S INCLUDED:

**ROASTER**  
HEATLIE HB6000DS

**GAS BOTTLE**  
9L LPG GAS BOTTLE

**GAS REGULATOR STAND**  
REGULATES/REDUCES PRESSURE FROM THE  
GAS BOTTLE TO THE APPLIANCE



## SET-UP INSTRUCTIONS:

### GAS BOTTLE AND LINE FITTINGS

- Gas bottle: Place a 9kg gas cylinder on Regulator Stand to the side of the roaster.
- Connect the regulator to the bottle. Note: This is a low-pressure appliance and a pressure regulator must be used.
- Tighten gas bottle connection anti-clockwise. Keep the gas line away from potential hot surfaces.
- CONNECT gas line from Roaster to the regulator noting the grooves that the bayonet lines up with (example to right). Once inserted twist to lock the connection (Important).
- Leak Test: With the gas line connected, turn gas on at bottle and check for leaks. Use soapy water and brush or spray over joints on gas bottle and connection at hotbox and watch for bubbles.



### LIGHTING/IGNITION

- Turn the gas control to the OFF position and open the roaster hood lid.
- Turn on gas by pushing down the knob and slowly turn to HIGH (anti-clockwise). This will also engage the flame failure. Continue to hold down knob.
- You will hear a click; this will ignite the burner. If the burner does not light, try again.
- The flame will be on HIGH so adjust the flame to the required heat.
- After use turn the knob control to OFF position and close the valve at the gas cylinder.



\*Note - Gas bottle should be chained to regulator stand when in use

NEED HELP?  
CALL OUR OFFICE

8346 5545



OUT OF HOURS SUPPORT: 1300 161 024